Bluetooth
DIGITAL PHOTO FRAME

User Manual
DPF-752

Thanks for purchasing our product, please read user manual carefully before use

SAFETY PRECAUTIONS

Thanks for purchasing our digital photo frame **DPF-752**. Before operating this player, please read this manual and retain it for future reference.

This symbol is intended to alert the user of the presence of non-insulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to a person.

This symbol is intended to alert the user of the presence of important operation and maintenance instructions in the Digital Picture Frame User’s Manual.

CAUTION
TO REDUCE THE RISK OF FIRE OR ELECTRONIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

CAUTION
TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE PLASTIC CASE OR SERVICABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL ONLY.

SAFETY PRECAUTIONS

Thanks for purchasing our digital photo frame. Before operating this player, please read this manual and retain it for future reference.

Warning

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.
To avoid electric shock, do not touch the plug with moist or wet hands.
Please immediately cut off power supply if you notice any abnormality.
Do not attempt to open the digiframe to change or refit any parts. Refer to Qualified Personnel.
Do read this manual carefully before use, and retain it for future reference.

Safety Notice

1. Ensure correct voltage supply to the machine before use.
2. If liquid and dirt should fall onto frame, remove plug. Only resume use once qualified personnel have confirmed it as safe to use.
3. Always unplug the power adapter after use.

Location

1. Put frame in well ventilated location to avoid over heating.
2. Do not place frame in hot room or in direct sunlight.
3. Stand frame horizontally on a flat, level surface, or hang firmly on to the wall.
4. Do not place frame in dusty environments.

Condensation

Dew may form if you transfer the frame suddenly from a cold to warm location. If condensation occurs and the frame does not start normally, leave for 3 hours before using again in order to allow the temperature of the unit to balance with its environment.

Cleaning

Use a soft cloth with a SMALL AMOUNT of neutral wash to clean the unit casing, screen and remote control. Do not use abrasive, alcoholic or caustic based substances.

Main Features

User friendly display
Supports playback for JPEG/MUSIC/WMA/some format of MP4.
Supports Clock/Calendar/Alarm Clock function.
Supports picture slide show with music as background.
Different transition effect for JPEG files.
Supports USB1.0/2.0 (high-speed)
Supports SD, MS, MMC Card, CF, XD card, Usb drives.
Supports receiving of files from Bluetooth devices.

CONTENTS

1. INTRODUCTION 4
   1.1. Control Panel 4
   1.2. Remote Control 4
2. GETTING STARTED 5
   2.1. Selecting language 5
   2.2. Slideshow mode set up 5
   2.3. Adjusting brightness, contrast and saturation 5
   2.4. Setting date and time 6
3. SELECTION MODE AND FILE SOURCE 6
   3.1. Selecting TEXT or PICTURE file 6
   3.2. Navigating in TEXT files 6
   3.3. PHOTO functions 7
      3.3.1. Manual mode 7
      3.3.2. Pre-visualization of images 7
      3.3.3. Slide show mode 7
4. EDIT 8
   4.1. Duplicating files 8
   4.2. Deleting files or a subdirectory 8
5. MUSIC, MOVIE AND COMBO FUNCTION 8
6. BLUETOOTH FUNCTION 9
7. TV OUT FUNCTION 9
8. TROUBLE SHOOTER GUIDE 10
9. TECHNICAL SPECIFICATION 11

For further information on the TEXET range, please refer to www.texet.com

1. INTRODUCTION

1.1. Control Panel



1	Power on/off	6	Navigate down	11	Earphone port
2	Navigate left	7	Return	12	DC In
3	Navigate right	8	USB port	13	Remote control sensor
4	Enter / Play	9	Mini USB port	14	CF card reader port
5	Navigate up	10	AV Out	15	SD/MMC/MS/XD card reader port

1.2. Remote control

1	POWER	Switch on/off and standby
2	FULL SCREEN	Full screen on/off
3	VIDEO	Switch to TV mode
4	MUTE	Mute on/off
5	MENU	Return to main menu
6	SETUP	View menu setup
7	VOL+/-	Adjust volume
8	▲▼◄►	Up/down/left/right navigation
9	ENTER/PLAY	Enter / play selected file
10	PAUSE	Pause play
11	STOP	Stop play
12	RETURN	Return to previous menu
13	ROTATE	Rotate image
14	ZOOM	Zoom in on image
15	SLIDE SHOW	Switch to photo slide show
16	SLIDE SHOW MUSIC	Switch to photo slide show with music
17	PHOTO MODE	Switch to photo mode
18	MUSIC MODE	Switch to music mode
19	VIDEO MODE	Switch to video mode
20	CALENDAR	Switch to calendar mode
21	⏮	Previous chapter
22	⏭	Next chapter
23	EDIT	Switch to edit mode
24	12 PICTURE	Switch to 12 picture view mode

2. GETTING STARTED

2.1. Selecting Language

Select SETUP by pressing ◄ or ► navigator buttons and press ENTER to confirm.



Select by pressing ► navigator button and press ENTER to confirm.

Select your language (English, Spanish, German, French, and Italian) and press ENTER to confirm.

Exit language menu by pressing MENU button or ◄ navigator button.

2.2. Slideshow Mode set up

Select by pressing ▼ navigator button and press ENTER to confirm.

2.3. Adjusting brightness, contrast and saturation

Select by pressing ▼ navigator button and confirm by pressing ENTER.
You have the option of adjusting brightness, contrast and saturation.
Choose the parameter to be adjusted using ▲ and ▼ navigator buttons and press ENTER to confirm.
Make adjustment by using ▲ and ▼ navigator buttons.
Exit menu by pressing MENU or ◄ navigator button.

Note: Selecting RESET PARAMETERS will cancel manual changes and revert frame to default, factory setting. Press ENTER to confirm changes.

2.4. Setting date and time



Select by pressing ▼ navigator button and press ENTER to confirm.
Use ▲▼ navigator buttons to adjust year, month, day and time.
To accept date and time, press ENTER to confirm changes.
Press this button once again to return to the main menu.



Once back at Main MENU, select CALENDAR, and press ENTER to activate date and time.

3. SELECTION MODE AND FILE SOURCE

3.1. Selecting TEXT or PICTURE file

Select TEXT or PICTURE using ◄ or ► navigator buttons and press ENTER to confirm.

Select file source (SD/MMS/MS/XD USB) using ▲▼ navigator buttons and press ENTER to confirm.



Select the file you want to display using ▲▼ navigator buttons and press ENTER to confirm.

Note:
If you want to go back to the superior level of the menu, press down on ◄ navigator button.

3.2. Navigating in TEXT files

During reading of the file:

- select the page by pressing the ◄ or ► navigator buttons
- make a line stream in by pressing the ▲▼ navigator buttons
- go backwards in the menu by holding down on the STOP button.

(Note: the machine does not support files other than of .txt format)

Simply press down on MENU button to return to Main Menu.

3.3. PHOTO functions

3.3.1 Manual mode

Upon display of photo, hold down PAUSE button to switch to manual mode.
In this mode, you can perform the following actions:

- Rotation: hold down continuously on ROTATE button to rotate the photo clockwise.
- Display full page: hold down on the FULLSCREEN button.
- Zoom (4 positions): hold down continuously on the ZOOM button.
- Proceed to the next photo: hold down on ◄ or ► navigator buttons.

Note:
You can switch to slide show mode at any time by holding down on the PLAY button. The reading speed depends on file size; for example the larger the display size, the longer the waiting time will be.

3.3.2. Pre-visualization of images

For fast and easy viewing, Press 12 PICTURE button to obtain pre-visualization of 12 images.

Use ▲▼◄ ► navigator buttons to select photo and press ENTER to display.

3.3.3. Slide show mode

Upon display of a photo, the slide show mode is started (automatic mode displayed at the bottom of screen).
If you have come from manual mode, hold down PLAY button.
Select the desired function with the aid of the ▲▼◄ ► navigator buttons and press ENTER to confirm.





Manual Mode

4. EDIT



Select EDIT by pressing ◄ or ► navigator buttons and press ENTER to confirm.

Select the source type (SD/MMS/MS/XD USB) by pressing ►▼ navigator buttons and press ENTER to confirm.



Select the file you want to edit by pressing ►▼ navigator buttons and press ENTER to confirm ( ).



4.1. Duplicating files

Select the file you want to duplicate by pressing ►▼ navigator buttons (a paw print will appear to the left of file name) and EDIT button to reveal -Return, -Duplicate and -Delete). Select and press ◄navigator button to select card or USB source.

4.2. Deleting files or a subdirectory

Select the file by holding down on the EDIT button and then select . Press ENTER to confirm.

5. MUSIC, MOVIE AND COMBO FUNCTION



Select MUSIC (MOVIE OR COMBO) by pressing ◄ or ► navigator buttons and press ENTER to confirm.

Select the source type (SD/MMS/MS/XD USB) by pressing ►▼ navigator buttons and press ENTER to confirm.

You can also use the remote control to select MUSIC or VIDEO MODE.

6. BLUETOOTH FUNCTION



Select SETUP by pressing ◄ or ► navigator buttons and press ENTER to confirm.

Select by pressing the ▼ navigator button and press ENTER to confirm.

Switch on the Bluetooth device (e.g. mobile phone, PC) that you want to transfer files from and conduct search for DPF-752. The search will identify frame as “TEXETDPF752” and you will be prompted for a password code. Type in 0000 and follow any prompts from device. Transmission of selected picture and music files from Bluetooth device (mobile phone, PC) can now happen. Once the files are transferred, they will be stored in the internal memory.

Select MUSIC (MOVIE OR COMBO) by pressing ◄ or ► navigator buttons and press ENTER to confirm.

Select the source type (SD/MMS/MS/XD USB) by pressing ►▼ navigator buttons and press ENTER to confirm.

You can also use the remote control to select MUSIC or VIDEO MODE.

NB: Bluetooth on the device is always turned on.

7. TV OUT FUNCTION:

Please switch TV mode to AV mode on your TV set.

Power on digital photo frame and enter main interface.

Connect the TV-out cable with digital photo frame as per below picture.

Connect the other end of TV-out cable to your TV

Press “Video” button once on your remote control to switch to AV out mode.

Then the display of the digital photo frame shall be black and the main interface of the digital photo frame shall appear on your TV set

Use the remote control to navigate to desired functions

8. TROUBLE SHOOTER GUIDE

If the photo frame does not function correctly, please read the following information carefully. Before requesting technical assistance, you need to identify the problem:

Failure symptom	Probable cause and possible solution
No power supply	If there is no power supply, check that the photo frame is well connected to its power supply and the DC In cable is not loose.
No display	Check that you have inserted a compatible memory card or USB key into the appropriate readers/ports. Only JPG and TXT formats are supported.
The remote control does not function.	1. The distance is too far from remote sensor panel or the angle exceeds 30 degrees. 2. The battery of the remote control is discharged. 3. The infrared sensor is experiencing interference by another source (e.g. solar rays)
Your photo frame dies or reverts back to the welcome screen.	This may be provoked by an electrostatic environment. You need to make a stop/forward step of your photo frame, if you know its origin, and keep the frame away from the source generating electrostatic problems (ESD).
It does not function with PC	The digital photo frame will not function when connected to a PC. The USB port is intended to receive USB keys uniquely in order to read .JPG or .TXT files.
My Bluetooth is enabled but device isn't connecting with the digiframe.	1. Please note that our digi frame is compatible with most popular Bluetooth enabled devices. Please ensure that Bluetooth is switched on and the correct passkey has been typed in. If not, please repeat Step 6. 2. Your Bluetooth device doesn't have the necessary profiles for sending files. Please refer to your Bluetooth manufacturer user manual.

9. TECHNICAL SPECIFICATION

Screen size: 7 inches
Supported image file format: .JPG
Supported audio files: MP3, WMA
Supported video files: MPEG4, DIVX
Supported text file format: .TXT
Acceptable photo cards: MS, MMC, SD, XD, CF
USB ports: USB 1.1 and USB 2.0
Power supply: AC 110V-240V~60/50Hz (DC9V)
Max power consumption : 13 W
Disposition: placed or suspended
Internal memory and Bluetooth function
Dimensions (with frame): 233(L) x 178(W) x 38(H) mm
Weight of Frame: 0.7 Kg